

m200 Blue
mrHandsfree® **Beat**

USER'S MANUAL

GB NL FR D



DECLARATION OF CONFORMITY

We, the undersigned

Company:	TE-GROUP nv
Address:	Kapelsestraat 61, 2950 Kapellen - BELGIUM

declare, that the following equipment:

Product Name:	BLUE BEAT M200
Product Type:	Bluetooth® Stereo Speaker

Conforms with the requirements of European Council Directive 99/5/EC



Joseph van Oosterum, CEO TE Group NV, March 2013

-----QRG/BLUE BEATm200/04-13/V01-----

ILLUSTRATIONS

ILLUSTRATION I






ILLUSTRATION II



CUSTOMER SUPPORT

For all product related questions, please contact:

Voor alle productgerelateerde vragen kunt u zich wenden tot onze supportafdeling:

Pour toutes les questions relatives à l'utilisation de ce produit, veuillez contacter notre Service Support Client:

Für alle produktbezogenen Fragen kontaktieren Sie bitte:

support@te-group.com

WHAT YOU NEED TO KNOW – QUICK START!



Blue BEAT charging

- With USB cable

Turning ON/OFF

- By ON/OFF power switch

PAIR your music device with the Blue BEAT first!

= establish Bluetooth® connection between music device & Blue BEAT stereo speaker

Check the successful connection status with Blue BEAT on your music device!

→ YOUR BLUE BEAT IS NOW READY FOR USE!

RECONNECTION between music device and Blue BEAT

- Automatic reconnection, no need to press **MODE** button
- Manual reconnection, by pressing **MODE** or using Bluetooth® menu of your music device

PACKAGE CONTENTS & PARTS

SEE ILLUSTRATION I

1. ON/OFF Power Switch
2. LED Indicator Light
- 3.4-5. Music buttons
6. Microphone
7. USB charging socket (DC5V)
8. Audio socket (AUX)
9. USB cable (for charging)
10. 3.5 mm audio jack cable (for NON-Bluetooth® devices)
11. Battery compartment cover (500 mAh 3.7V rechargeable lithium polymer battery inside)
12. Round feet

! Please do not use any other chargers, cables or battery than the ones included in this package!

PLACEMENT


SEE ILLUSTRATION II

Insert the round feet (12) in the slot to provide balance and add stability when placing the Blue BEAT on any kind of surface.

CHARGING THE BATTERY

1. Plug the USB cable (9) into the USB charging socket (7) of the Blue BEAT.
2. Plug the other end of the USB cable (9) into your computer or USB charger.
3. The red LED indicator (2) on the Blue BEAT will light up and your Blue BEAT will start charging.
! Red LED indicator (2) turns off when battery is fully charged!
4. The Blue BEAT's battery offers up to 10 hours music time.
5. When battery is running low, red LED indicator (2) will start to flash. Music time may vary from usage (volume).

BUTTON OPERATION



BUTTON	HOW?
	<ul style="list-style-type: none">- PRESS ONCE TO PLAY THE MUSIC- PRESS ONCE TO PAUSE THE MUSIC- PRESS ONCE FOR MANUAL PAIRING & RECONNECTION BETWEEN BLUE BEAT AND BLUETOOTH® MUSIC DEVICE- PRESS ONCE TO ACCEPT A CALL- PRESS ONCE TO END A CALL- PRESS AND HOLD TO REJECT A CALL
	<ul style="list-style-type: none">- PRESS ONCE TO JUMP TO NEXT SONG- PRESS AND HOLD TO INCREASE VOLUME
	<ul style="list-style-type: none">- PRESS ONCE TO JUMP TO PREVIOUS SONG- PRESS AND HOLD TO DECREASE VOLUME

TURNING BLUE BEAT ON / OFF

To turn the Blue BEAT ON:

Slide the Power Switch (1) to the 'ON' position. The blue LED indicator (2) will start flashing and you will hear a melody indicating that the Blue BEAT is entering pairing mode and is starting to search for available Bluetooth® devices.

To turn the Blue BEAT OFF:

Slide the Power Switch (1) to the 'OFF' position. The Blue LED indicator (2) will turn off indicating that the Blue BEAT is now turned off.

PAIRING THE BLUE BEAT WITH A BLUETOOTH® MUSIC DEVICE

You are required to pair the Blue BEAT with your **Bluetooth® music device (*)** once before using it.

Slide the Power Switch (1) to the 'ON' position.

The blue LED indicator (2) will start flashing and you will hear a melody indicating that the Blue BEAT is entering pairing mode and is starting to search for available Bluetooth® devices. The Blue BEAT is now ready for pairing.

Let your Bluetooth® music device search for other Bluetooth® devices (please refer to the manual of your Bluetooth® music device for more information).

Select the **Blue BEAT** out of the list with found devices on your Bluetooth® music device and enter PIN code **0000** to pair both devices (**). You will hear a short beep.

The blue LED indicator (2) will flash every 4 seconds.

Once the Blue BEAT is successfully paired, you can use it to listen to your favorite music wirelessly in stereo.

(*) Bluetooth® music devices are all Bluetooth® stereo music devices that support Bluetooth® A2DP profile (e.g. iPhone™, iPad®, music phones, laptops, Android® phones & tablets, ...).

(**) PIN code is not always required.

Note!

The Blue BEAT will automatically reconnect to the last connected device when the Blue BEAT is turned ON again.

In case your Bluetooth® music device does NOT reconnect automatically with the Blue BEAT you can:

- Reconnect manually with your Bluetooth® music device (please refer to the manual of your Bluetooth® music device for more information).
- Reconnect manually by pressing **MODE** button once on the Blue BEAT.

HANDSFREE FUNCTION

To answer/end/reject a call

Quick press **MODE** to answer a call.

Quick press **MODE** to end a call.

Long press **MODE** to reject a call.

To make a call

Dial a number with your phone. The call is automatically transferred to the Blue BEAT.

CONNECTING THE BLUE BEAT WITH A NON-BLUETOOTH® MUSIC DEVICE

You can also play music from a **NON-Bluetooth® music device** on the Blue BEAT by using the 3.5 mm jack cable (10). Plug the jack cable (10) into the audio socket (8) of the Blue BEAT. Plug the other end of the jack cable (10) into the audio socket of your music device.

Note!

When playing music from a device connected to the Blue BEAT using the jack cable (10), all music functions (play/pause/FWD/BWD/VOL+/VOL-) need to be operated from the music device, NOT from the Blue BEAT's music buttons (3-4-5).

Due to many slight differences in music devices and phones, above mentioned operations may vary!

CUSTOMER SUPPORT

For all product related questions, please contact: support@mrhandsfree.com

GUARANTEE

Mr Handsfree is a registered trademark of TE-Group NV. The mr Handsfree brand stands for superior product quality and outstanding customer service. That is why mr Handsfree warrants this product against all defects in material and workmanship for a period of **two (2) years** from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of mr Handsfree under this guarantee can be downloaded from our website: www.mrhandsfree.com.